

Turbine Compact IP Stations

Getting Started for AlphaCom



The information in this document pertains to the Turbine Compact IP Stations TCIS-1/TCIS-1-V, TCIS-2, TCIS-3, TCIS-4, TCIS-5, TCIS-6, TKIS-1.

Turbine TCIS-1/TCIS-1-V Station Keys & Functions




Turbine TCIS-6 Station Keys & Functions



1 Station Connections

1.1 External Connectors



The following table is an overview of the main connectors involved when installing the Turbine IP Stations.


Ethernet/Power	10/100 Mbps Ethernet RJ-45 port for LAN (uplink) connection. Supports PoE (802.3af). Draws power from either spare line or signal line.
Secondary Power	24 VDC (16 – 48 V) secondary power is provided from an external adapter.
Relays	There is one Double Throw relay contact with 60W switching power. COM, NO, NC contacts are provided. Max: 250VAC/220VDC, 2A, 60W.
Input/Output	6 general purpose I/Os are available. Each I/O can be configured as either button input or LED driver.
Audio Line Out	A balanced 600 ohm audio line out with induction loop signal

1.2 Power Supply

The Turbine Station supports Power over Ethernet (PoE, IEEE 802.3 a-f) where power can be drawn from either the spare line or signal line.

If PoE is not available, the Turbine Station can be connected to a 24 VDC local power supply.

1.3 Network Connection




There is one RJ-45 port located on the Turbine station that is used as the PoE/LAN port.

1.4 Input/Output Connections

There are 6 I/O connection options for the Turbine Station. These connections are used as relay contacts for door lock control and external I/O devices.

2 Station Configuration



2.1 Logging into the Turbine Station

The Turbine Station features an embedded web interface which allows users to log in via a standard web browser.

To do this, your PC and the Turbine IP station have to be connected together via a PoE switch using network cables:

1. Connect the PC to the PoE switch
2. Connect the PoE port on the station to the PoE switch

When the Turbine Station is connected to the network, the **IP address** of the station is automatically obtained in one of two ways:

1. IP address obtained from a **DHCP server**
2. If there is no DHCP server, an IP address in the range **169.254.x.x** will be assigned.

To make the station speak its IP address:



- Press the **call button** on the station
- when the station is not yet registered

Access the station by logging into the web interface using a standard web browser:

1. Open a web browser
2. In the browser's address bar, type the station IP address and press the ENTER key
- The station login page will be displayed.

To log into the station:



1. Click **Login**
2. Enter the default User name: **admin**
3. Enter the default password: **alphaadmin**

2.2 Station Main Settings

- Click **Station Main > Main Settings** to access the page for configuring station mode and IP parameters.

Station Mode

- Select the **Use Alphacom** radio-button

Turbine Frontboard

Depending on the type of Turbine Compact station, select one of the options from the drop-down box:

- Kit
- **Normal (TCIS-1, TCIS-2, TCIS-3)**
- **OLED Labels (TCIS-4, TCIS-5)**
- **Scrolling Station (TCIS-6)**

Registration Settings

- Enter the IP address of the AlphaCom server/exchange in which the IP station is to be a subscriber in the **AlphaCom IP-address** field.
- Enter the directory no. of the station in the **Directory Number** field.
- If a directory number is not entered, the station will register with its MAC address. The MAC address is found on the **Station Information** page and needs to be entered into AlphaPro.

IP Settings

- **DHCP** – Select this option if the IP station shall receive IP Settings from a DHCP server.
- **Static IP** – Select this option if the IP station shall use a static IP address. Enter values for:
 - **IP-address**
 - **Subnet-mask**
 - **Gateway**
 - **DNS Server 1** (optional - for network administration)
 - **DNS Server 2** (optional - for network administration)
 - **Hostname** (optional - for network administration)

Read IP Address

- Check the **Read IP Address** box to enable an unregistered station to speak the IP address when the call button is pressed.

Click **Save** followed by **Apply** to apply the new configuration settings.

2.3 Audio Settings

To configure audio settings:

- Select **Advanced AlphaCom > Audio** from the menu

Description	Configuration
Microphone Sensitivity:	5 0 = disabled
Automatic Volume Control:	<input type="checkbox"/> Volume depends on noise level
Debug Automatic Volume Control:	<input type="checkbox"/> Shows current volume level on OLED display
Conversation Mode:	Full Open Duplex
Audio profile:	Normal
Line Out Source:	Speaker Line out can play audio either from VoIP signal (Speaker) microphone

Microphone Sensitivity

- Select the sensitivity level in the range 0 to 7 from the drop-down box. The default setting is 5.

Automatic Volume Control

- Check box to enable automatic volume control that is adjusted according to the noise level

Debug Automatic Volume Control

- Check box to show current volume level on OLED display

Conversation Mode

- **Full Open Duplex:** Normal mode with echo cancellation
- **Robust Duplex:** Option used when open duplex fails due to excessive speaker loudness, microphone overload or very high nonlinear distortions.
- **Half Duplex Switching:** Switches speech direction depending on who speaks the loudest
- **Push-To-Talk:** Half-duplex communication. Initially the microphone is shut off. Push the M-button to open the microphone, and release to listen. (TCIS-1 station only)
- **Open:** Full Open Duplex without echo cancellation

Line Out Source

Plays audio either from VoIP signal (**Speaker**) or direct from **Microphone**.

2.4 I/O Settings

- Select **Advanced AlphaCom > I/O Settings** from the menu

Description	Configuration
Relay:	Output 0 (RCO 0)
I/O Pin 1:	Input 1
I/O Pin 2:	Input 2
I/O Pin 3:	Input 3
I/O Pin 4:	Input 4
I/O Pin 5:	Input 5
I/O Pin 6:	Input 6

Note: Changes requires application reboot

- Select either **Input** or **Output** options from the drop-down box for **I/O Pins** 1 to 6.

2.5 OLED Labels

- ① Note that only Turbine stations configured with **OLED Labels (TCIS-4, TCIS-5)** under **Main Settings** will have this menu option.

- Select **Advanced AlphaCom > OLED Labels** from the menu

Description	Configuration
OLED 1 Display Text:	Guardroom
OLED 1 Font Size	12
OLED 2 Display text:	Administration
OLED 2 Font Size	16
OLED Brightness	Bright
Start Scrolling After:	5 minutes

OLED Display Text

- Enter display text in the relevant fields for OLED 1 and OLED 2.

OLED Font Size

- The font size can be either **12** or **16**

OLED Brightness

- Brightness: **Default, Bright, Extra Bright**

2.6 Address Book

- ① Note that only the Turbine station configured as a **Scrolling Station (TCIS-6)** under **Main Settings** will have this menu option.

- Select **Advanced AlphaCom > Address Book** from the menu

Description	Configuration
Default Display Text:	Scroll to Select
Font Size	12
OLED Brightness	Default
Start Scrolling After:	5 minutes
Upload Address Book:	X:\01 Documentation\Documentation in Browse...

Default Display Text

- The idle text shown in the display may be changed. The default text is: **Scroll to Select**

Font Size

- The font size can be either **12** or **16**

OLED Brightness

- Brightness: **Default, Bright, Extra Bright**

Start Scrolling After

- Set the time in minutes after which scrolling should start

Upload Address Book

AddressBook	
A	
1	118;Guardroom
2	121;Logistics
3	201;Stockroom
4	202;Meeting Room
5	203;Accounting
6	204;Garage
7	205;Reception
8	206;Canteen

A CSV file consisting of directory numbers and display text with the semi-colon character (;) as delimiter may be uploaded.

- Click **Browse** to upload a CSV file

2.7 Sound Detection

- Select **Advanced Alphacom > Sound Detection** from the menu

Description	Configuration
Sound Detection status:	ENABLED
Minimum amplitude (dBA):	75
Minimum duration of audio (ms):	350
DAK key to activate:	5
Minimum time before reactivation (ms):	2000
Report DAK key off after (ms):	200

Save

Sound Detection Settings

Here you can set the minimum amplitude and duration of the audio, the DAK to activate, etc.

3 LEDs on Station Front Plate



Status LEDs

- Bell icon** lights **yellow** when a call is placed and ringing
- Talk icon** lights **green** when a call is active and in conversation
- Door icon** lights **red** when the door is unlocked or relay is active

Talk Icon: Flashing at 1 second intervals



- Station has no connection to the AlphaCom server/exchange.
- Possible reasons:**
 - No connection to Ethernet
 - Wrong AlphaCom XE IP address configured
 - Invalid IP address
 - No gateway or wrong gateway to the AlphaCom server/exchange

Talk Icon: Flashing at 5 second intervals



- Station connected but NOT registered in the AlphaCom server/exchange.
- Reason:**
 - Station has not been programmed in AlphaPro

4 Restoring Default Settings

4.1 Reset to Default with Activated DHCP

To reset:



- While **pressing any button**, power up the station by connecting to a PoE switch.
- Hold the button until the station audio starts counting, and release the button on **count 1**.
- Press and hold the button on **count 5** and release on **count 0**.
- Press the **call button** to make the station speak its IP address.

Default values

- Station IP address: (determined by DHCP server)
- Username: **admin**
- Password: **alphaadmin**

4.2 Reset to Default with Static IP

To reset:



- While **pressing any button**, power up the station by connecting to a PoE switch.
- Hold the button until the station audio starts counting, and release the button on **count 1**.
- Press and hold the button on **count 3** and release on **count 0**.
- Press the **call button** to make the station speak its IP address.

Default values

- Station IP address: **169.254.1.100**
- Username: **admin**
- Password: **alphaadmin**

5 Station Software Upgrade

- Start the TFTP server program and click **Browse** to select the folder containing the software image files
- Log on to the IP station web interface
- Select **Station Administration > Manual Upgrade**

Station Main	Station Administration	Advanced Alphacom	Advanced Network
Enter the following parameters:			
TFTP-server IP: 10 . 5 . 2 . 183			
Image file: tsi-3.0.2.2			
Save settings			
Manual Upgrade			

- Enter the IP address of the **TFTP server** (your PC's IP address)
- Enter the prefix (e.g. **tsi-3.x.x.x**) to the software image files in the **Image file** field
- Click **Save settings** to store the data
 - The station will now try to contact the TFTP server. If the response is **TFTP_CONN_OK** the settings are saved, and the **Upgrade** button will appear.
- Click the **Upgrade** button to upgrade the software on the IP station.
 - The upgrade procedure takes about 3 minutes.