

VINGTOR STENTOFON

Turbine SIP Station Mounting Manual

1 Turbine SIP Stations

This document describes the dimensions, mounting procedure, and connections of the Turbine SIP Stations.


Zenitel takes no responsibility for damages caused by improper or inadequate mounting.

The Turbine SIP product range comprises the following stations & accessories:

Item Number	Type	Item Name
1008211010	TCIS-1SIP	Turbine SIP Station
1008211020	TCIS-2SIP	Turbine SIP Station
1008211030	TCIS-3SIP	Turbine SIP Station
1008211040	TCIS-4SIP	Turbine SIP Station
1008211050	TCIS-5SIP	Turbine SIP Station
1008211060	TCIS-6SIP	Turbine SIP Station
1008140010	TA-1	Turbine On-Wall Back Box
1008140020	TA-2	Turbine Flush Mount 2-Gang Double-Depth Back Box
1008140050	TA-5	Turbine Bracket for Flush Mount Back Box




1.1 Station Dimensions



2 On-Wall Surface Mounting

2.1 On-Wall Surface Mount Back Box - TA-1



Mounting holes are to be drilled as shown.

Max. recommended screw diameter: ISO M6 or ANSI 1/4".
Screw length must be greater than 25 mm or 1".


A4 stainless steel socket head screws/bolts are recommended.
Max. recommended screw head diameter: 9.5 mm or 3/8".

Optional washers for extra protection against corrosive effects between surfaces are provided.

They should be placed at the bottom of the 4 mounting holes.

Grommets and an M20 cable gland are provided.

2.2 On-Wall Surface Mounting Procedure




- ① **The Gasket MUST be mounted to seal the station!**
- ① **Ensure the station is mounted vertically with the microphone aperture facing down.**
- ① **Ensure there is enough clearance under the station so that the microphone aperture is NOT smothered.**
- ① **Place the washers at the bottom of the 4 mounting holes on the back box.**
- ① **Use the grommets and M20 cable gland provided for the cable holes on the back box.**

1. Mount the back box onto the wall
2. Fit the gasket onto the back box with the ridged side facing down
 - Plug the Ethernet cable into the RJ-45 port on the station
3. Mount the Turbine station onto the back box with the M5 fasteners provided applying 1.5 Nm torque

3 Flush Mounting


3.1 Flush Mount 2-Gang Double-Depth Back Box - TA-2



① It is recommended to utilize back boxes with weep holes at the bottom.

3.2 Flush Mount Bracket - TA-5

① **The TA-5 Bracket is mandatory for flush mounting.**




Fits US 2-GANG electrical boxes.

Recommended screw diameter: up to M4 (5/32")
Use screw recommended by back box manufacturer.

3.3 Flush Mounting Procedure

① **The Gasket MUST be mounted to seal the station!**




- ① **Ensure the station is mounted vertically with the microphone aperture facing down.**
- ① **Ensure there is enough clearance under the station so that the microphone aperture is NOT smothered.**
- ① **Apply silicone sealant all around the aluminum frame of the station, making sure to leave the microphone aperture open.**

1. Mount the 2-gang back box into the wall
2. Mount the bracket onto the back box
3. Fit the gasket onto the bracket with the ridged side facing down
 - Plug the Ethernet cable into the RJ-45 port on the station
4. Mount the Turbine station onto the bracket with the M5 fasteners provided

4 Connections

The Turbine SIP station has a RJ-45 PoE/LAN port, and 6-pin & 10-pin external connectors.



Ethernet / Power	10/100 Mbps Ethernet RJ-45 port for LAN (uplink) connection. Supports PoE (802.3af). Draws power from either spare line or signal line.
Secondary Power	24 VDC (16 – 48 V) secondary power is provided from an external adapter.
Relays	There is one Double Throw relay contact with 60W switching power. COM, NO, NC contacts are provided. Max: 250VAC/220VDC, 2A, 60W.
Input/Output	6 I/Os are available. Each I/O can be configured as either input, output, or LED driver.
Audio Line Out	A balanced 600 ohm audio line out with induction loop signal

① Use cables crimped with ferrules for terminal block connectors



- When the station is connected to the network, its IP address is automatically obtained from a DHCP server or an IP address in the range 169.254.x.x will be assigned.
- To make the station speak its IP address, press the call button on the station.

