
VINGTOR STENTOFON

Exigo Ex Access Panels & Turbine Ex Intercoms

Installation, & Maintenance Procedures









Document Contents

1 Basic information

1.1 Revision history

| Doc.no. | Rev. | Date | Prepared by | Revision text | App. by Ex r | esponsible |
|------------|------|------------|----------------|---|--------------|-----------------|
| A100K11499 | 1 | 05.01.2015 | Svend E.Nilsen | New document | 05.01.2015 | Erik Bjørkander |
| A100K11499 | 1.1 | 05.02.2015 | Svend E.Nilsen | Minor correction, labeled headset as ATEX only | 05.02.2015 | Erik Bjørkander |
| A100K11499 | 1.2 | 03.03.2015 | Thomas Hægh | Corrected IS parameters (chapter 3.3.2) | 03.03.2015 | Erik Bjørkander |

1.2 Scope

This document describes the installation and maintenance procedures for the VINGTOR - STENTOFON Exigo Ex Access Panels and Turbine Ex Intercom Stations, henceforth commonly referred to as "Ex Products", and their intended audio accessories. The following models are covered by this manual.

| Item number | Search name | Item Name | | |
|---------------|---------------------------|---|--|--|
| Exigo Ex PA | Exigo Ex PA access panels | | | |
| 1023221511 | EAPFX-1 | Exigo Industrial Ex Access Panel, 1 button, Flowire | | |
| 1023221516 | EAPFX-6 | Exigo industrial Ex Access Panel, 6 buttons, Flowire | | |
| Turbine Ex in | tercom units | | | |
| 1008123010 | TFIX-1 | Turbine Full-Size Ex Intercom Station 1 | | |
| 1008123020 | TFIX-2 | Turbine Full-Size Ex Intercom Station 2 | | |
| 1008123030 | TFIX-3 | Turbine Full-Size Ex Intercom Station 3 | | |
| 1008123040 | TFIX-4 | Turbine Full-Size EX Intercom Station 4 | | |
| Ex audio acce | Ex audio accessories | | | |
| 2330040026 | AK5850HS | Ex-Approved Headset with plug ** | | |
| 1008150025 | TAX-2B | Ex-Approved Cable for Headset with PTT Button | | |
| 1008150030 | TAX-3 | Ex-Approved Handset with PTT, unterminated | | |
| 1023533511 | EMMAX-1H | Exigo Handheld Industrial Ex Microphone, 1 Button, IP66 | | |

^{**} Headset AK5850HS is only certified for use in ATEX areas (Not IECEx)

Page 2 Doc. no. A100K11499

1.3 Related Documentation

For further information, refer to the following documentation

| Doc.no. | Documentation | |
|------------|--|--|
| A100K11460 | Exigo Installation & Configuration Manual | |
| A100K11422 | Flowire Installation & Configuration Manual | |
| A100K11471 | Exigo User Manual | |
| A100K11194 | Turbine Stations Configuration Manual | |
| A100K11523 | Mounting Manual for EAPFX-1, EAPFX-6, TFIX-1, TFIX-2, TFIX-3, TFIX-4 | |
| A100K11525 | Connection Manual TAX-2b Ex-Approved plugbox and cable for Ex Headset AK5850HS | |
| A100K11526 | Connection Manual TAX-3 EX-approved Handset w/PTT, unterminated | |
| A100K11528 | Connection Manual EMMAX-1H Exigo Handheld Industrial Ex Microphone | |

1.4 Certificates

| ATEX Certificate number | Presafe 14ATEX5209 X | |
|---|----------------------|--|
| IECEx Certificate number | IECEx PRE 14.0029 X | |
| Certificates can be downloaded from www.vingtor-stentofon.com | | |



If the sign "X" is placed after the certificate number, it indicates that the equipment is subject to special condition for safe use.

Special condition for safe use:

The cable glands shipped with this product has an impact resistance of max 4J.

Due to low impact resistance of the cable glands, the units shall only be installed in areas where there is a low risk of impact.

If cable glands supporting high impact (7J) are used, the X condition does not apply.

2 About the Ex Products


2.1 The Industrial Ex product series

Before using this product, carefully read this manual and other manuals for compatible hardware. Retain instructions for future reference.

The Ex Products are approved according to IECEx and ATEX regulations, and bear the marking:

© II 2(2)G Ex e ib mb (ib) IIC T4 Gb (See chapter 3.5.4 marking for detailed information).

The following models and audio accessories are approved for use in hazardous areas



^{**} Headset AK5850HS is only certified for use in ATEX areas (Not IECEx)

Page 4 Doc. no. A100K11499

2.2 Ex Product Interface

The interface of the Ex Products consist of the elements in the following chapters.

2.2.1 Status LEDs

Present on all Ex Products.

Green Power LED

The Power LED is lit to indicate that the access panel is powered up.

The Power LED flashes to indicate that the device has no connection to the central equipment.

Yellow Fault LED

The Fault LED is lit to indicate that there are faults in the system.

The Fault LED flashes to indicate that the device is connected to (link OK), but not registered with the central equipment.

Red Call LED

The Call LED is lit when an intercom is in a conversation, or the microphone on an access panel is active.

2.2.2 Function Buttons

Present on all Ex Products.

These are fully programmable buttons which appear in different forms on different units.

Right-aligned Function Buttons have two programmable LEDs (green and red) to indicate status information related to the function.

For right-aligned Function Buttons, button protection covers can be attached to avoid a button being inadvertently pressed.

2.2.3 Numeric Keypad

Present on TFIX-1, TFIX-3 and TFIX-4.

These have a predetermined function.

Dialing buttons 0 - 9, present on TFIX-1 and TFIX-4, are used for calling specific numbers or triggering functions.

M-button, present on TFIX-1, TFIX-3 and TFIX-4, is used for answering calls, Push-To-Talk and changing from external to internal audio devices.

C-button, present on TFIX-1, TFIX-3 and TFIX-4, is used to cancel a current action or state.

2.2.4 Model specific interfaces



EAPFX-1

- One right-aligned Function Button
- Available area for labelling the button



EAPFX-6

- Six right-aligned Function Buttons
- Available areas for labelling the button

Page 6 Doc. no. A100K11499



TFIX-1

- Dialing buttons 0-9
- M-button
- C-button


Four function buttons, three of which are pre-programmed:

- + for volume up
- for volume down
- Audio button for changing between loud speaking and low speaking mode



TFIX-2

- Six right-aligned Function buttons
- Available areas for labelling the button



TFIX-3

- Call button
- M-button
- C-button



TFIX-4

- Dialing buttons 0-9
- M-button
- C-button

Four function buttons, three of which are preprogrammed:

- + for volume up
- for volume do
- Audio button for changing between loud speaking and low speaking mode

Page 8 Doc. no. A100K11499


2.3 Accessories

The following accessories are designed for use with any of the Ex Products.




AK5850HS

- Headset with boom microphone, curled cord and plug
- Plugs into TAX-2B
- Headset AK5850HS is only certified for use in ATEX areas (Not IECEx)




TAX-2B

- 10 m cable with Push-To-Talk button (PTT) and contact
- For headset AK5850HS
- Terminated on main board inside Ex Product



TAX-3

- Handset with Push-To-Talk button (PTT)
- Terminated on main board inside Ex Product



EMMAX-1H

- Microphone with Push-To-Talk button
- Terminated on main board inside Ex Product


Page 10 Doc. no. A100K11499

3 System design overview


3.1 Connection to central equipment

The Ex Products are connected to the central equipment rack using Ex certified 2-wire cable with shield. A Zenitel proprietary protocol, Flowire, is used to extend the Ethernet connection and support power distribution on the 2-wire cabling infrastructure.

To support the Flowire interface, the central equipment rack must be equipped with a Flowire Converter (FCDC2).



Network configuration 1



Network configuration 2 - redundant cabling in Ex zone

Page 12 Doc. no. A100K11499

3.2 Block diagrams for electronics (HW)

The Ex Products all use the same Printed Circuit Board Assemblies. These are:


- A100C08127 Front Board
- A100C08511 Main Board

The front board implements the user interface.

The main board implements the main functions. The board has the following interfaces:

- Interface to internal loudspeaker
- Interface to internal microphone
- Interface to audio accessories (headset, handset, handheld microphone)
- Interface to central equipment (Flowire)

The block diagram below shows the main components used in the Ex Panel design including connectors, barrier sections and cable entries.



3.3 Electrical parameters

The Ex Products are designed for the following input and output parameters.

3.3.1 Internal Microphone and Loudspeaker

| | one Input II J13 + - | Loudspeaker Output Terminal J9 8-9 | |
|----|-------------------------|-------------------------------------|--------|
| Uo | 4.5V | Uo | 6.3V |
| lo | 44mA | lo | 660mA |
| Po | 0.5W | Po | 01.1W |
| Со | 100 uF | Со | 100 uF |
| Lo | 40 mH | Lo | 0.3 mH |

Details on the loudspeaker and microphone are found in Chapter 6 Technical Data.

3.3.2 Audio Accessories

| | one Input J6-3 / J7-4 | Loudspeaker Output Terminal J6 1-2 | | PTT Switch Input / Hook Switch input Terminal J7 5-6 | |
|----|--------------------------|------------------------------------|--------|---|--------|
| Uo | 5.8V | Uo | 5.8V | Uo | 5.8V |
| lo | 952mA | lo | 952mA | lo | 952mA |
| Ро | 1008mW | Ро | 1008mW | Ро | 1008mW |
| Со | 597nF | Со | 597nF | Co | 597nF |
| Lo | 40µH | Lo | 40µH | Lo | 40µH |

The parameters above are a combination of all outputs connected together that can occur if separation distances in external accessories are below the limits in EN60079-11:2012.

Technical specification on the accessories are found in Chapter 6 Technical Data.

Only Ex-certified audio accessories which comply with the input and output values in chapter 3.3.2 may be used with the Ex Products.

The following Zenitel accessories comply with the input and output values stipulated above, and are approved for use with the Ex Products:

| Ex audio accessories | | | | |
|--|---|---|--|--|
| 2330040026 AK5850HS Ex-Approved Headset with plug ** | | | | |
| 1008150025 | TAX-2B | Ex Approved Cable for Headset with PTT Button | | |
| 1008150030 | 08150030 TAX-3 Ex-Approved Handset with PTT, unterminated | | | |
| 1023533511 | EMMAX-1H | Exigo Handheld Industrial Ex Microphone, 1 Button, IP66 | | |

^{**} Headset AK5850HS is only certified for use in ATEX areas (Not IECEx)

Page 14 Doc. no. A100K11499

3.4 Terminals and connectors


Terminal J8 and J10 Type Phoenix MK3DSH 3/ 2-5, 08-EX

| Hole diameter | 1.3 mm |
|---------------------------------------|---------------------|
| Screw thread | M3 |
| Tightening torque, min | 0.5 Nm |
| Tightening torque max | 0.6 Nm |
| Conductor cross section solid min. | 0.2 mm ² |
| Conductor cross section solid max. | 4 mm² |
| Conductor cross section stranded min. | 0.2 mm ² |
| Conductor cross section stranded max. | 2.5 mm² |

Terminal J13, J6, J7 and J9 Type Phoenix 1710049

| Hole diameter | 1.3 mm |
|---|----------------------|
| Screw thread | M3 |
| Tightening torque, min | 0.5 Nm |
| Tightening torque max | 0.6 Nm |
| Conductor cross section solid min. | 0.2 mm ² |
| Conductor cross section solid max. | 4 mm² |
| Conductor cross section stranded min. | 0.2 mm ² |
| Conductor cross section stranded max. | 2.5 mm ² |
| Conductor cross section stranded, with ferrule without plastic sleeve min. | 0.25 mm ² |
| Conductor cross section stranded, with ferrule without plastic sleeve max. | 1.5 mm² |
| Conductor cross section stranded, with ferrule with plastic sleeve min. | 0.25 mm ² |
| Conductor cross section stranded, with ferrule with plastic sleeve max. | 2.5 mm ² |
| Conductor cross section AWG/kcmil min. | 24 |
| Conductor cross section AWG/kcmil max | 12 |
| 2 conductors with same cross section, solid min. | 0.2 mm² |
| 2 conductors with same cross section, solid max. | 1.5 mm ² |
| 2 conductors with same cross section, stranded min. | 0.2 mm² |
| 2 conductors with same cross section, stranded max. | 1.5 mm² |
| 2 conductors with same cross section, stranded, ferrules without plastic sleeve, min. | 0.25 mm² |
| 2 conductors with same cross section, stranded, ferrules without plastic sleeve, max. | 0.75 mm² |
| 2 conductors with same cross section, stranded, TWIN ferrules with plastic sleeve, min. | 0.5 mm ² |
| 2 conductors with same cross section, stranded, TWIN ferrules with plastic sleeve, max. | 1.5 mm² |

3.5 Ex Protection Strategy



The Ex panel shall comply with the following standards:

- IEC 60079-0: Explosive atmospheres Equipment General requirements
- IEC 60079-7: Explosive atmospheres Equipment protection by increased safety "e"
- IEC 60079-11: Explosive atmospheres Equipment protection by intrinsic safety "i"
- IEC 60079-18: Explosive atmospheres Equipment protection by encapsulation "m"

3.5.1 Increased safety "e"

The mechanical enclosure complies with requirements for increased safety (Ex "e"). The Ex "e" part of the main board includes the Flowire screw terminals.

3.5.2 Encapsulation "m"

Encapsulating the entire board ensures compliance with requirements for protection by encapsulation (Ex "m"). Encapsulation removes the risk of sparks and provides thermal protection to ensure that the surface temperature of the potting compound is below T4 limit (135 °C).

The level of protection is "b" to comply with zone 1 equipment.

3.5.3 Intrinsic safety "i"

The following parts comply with requirements for intrinsic safety (Ex "i"):

- A100C08127 Turbine Front Board Extended
- EMMAX-1H Exigo Handheld Industrial Ex Microphone, 1 Button
- AK5850HS Ex-Approved Headset with plug
- TAX-2 Turbine Ex Approved Headset, Pluggable
- TAX-2B Turbine Ex Approved Cable for Headset with PTT
- TAX-3 Turbine Ex Approved Handset with PTT, Unterminated


The barrier design on the main board provides "b" level protection (Ex ib) to the intrinsically safe parts, supporting zone 1 requirements.

Um: 250V

Page 16 Doc. no. A100K11499

3.5.4 Marking

Based on the requirements of zone 1, T4 and the chosen concept of protection, the Ex Product shall include the following marking:




If the sign "X" is placed after the certificate number, it indicates that the equipment is subject to special condition for safe use.

Special condition for safe use:

The cable glands shipped with this product has an impact resistance of max 4J.

Due to low impact resistance of the cable glands, the units shall only be installed in areas where there is a low risk of impact.

If cable glands supporting high impact (7J) are used, the X condition does not apply.



3.5.5 Compliance

| IECEx | IEC 60079-0:2011, IEC 60079-7:2006, IEC 60079-11:2011, IEC 60079-18:2009 |
|-----------|--|
| ATEX | EN 60079-0:2012, EN 60079-7:2007, EN 60079-11:2012, EN 60079-18:2009 |
| Immunity | EN 60945, EN 61000-6-1, EN 61000-6-2, FCC-47 part 15B |
| Emissions | EN 60945, EN 61000-6-3, EN 61000-6-4, FCC-47 part 15B |

Page 18 Doc. no. A100K11499

4 Installation

4.1 General

Improper installation and operation of the Ex access panel will result in the invalidation of the quarantee.



The enclosure/housing must not be opened when the product is powered.

The installation and connection of Ex units may only be carried out by qualified approved personnel.

The maximum voltage (Um) that can be applied to the non-intrinsically safe connection facilities of associated apparatus without invalidating the type of protection is 250V Special condition for safe use

The "X" after the certificate number indicates that the equipment is subject to special condition for safe use.

The cable glands shipped with this product has an impact resistance of max 4J.

Due to low impact resistance of the cable glands, the units shall only be installed in areas where there is a low risk of impact.

If cable glands supporting high impact (7J) are used, the X condition does not apply.

4.2 Mounting

When the Ex Product is mounted directly onto a wall or mounting plate, it shall rest only on the fastening points provided for this purpose. The surface must be even and flat.




The unit must be mounted on the surface to prevent access from the back.

To mount the panel:

- 1. Open the enclosure by loosening the 12 screws that secure the front frame to the on-wall
- 2. Open the enclosure by pulling the front frame out 5 mm, keeping it parallel to the on-wall box. This is necessary to get clearing for the hinges. Then pull the right side of the front frame to fully open the enclosure. Make sure to not open the enclosure so far that cables between the front and back parts are pulled tight.
- 3. Fix the station to the wall, mounting plate or column with four screws that fit the four screw holes in each corner of the on-wall box (6.7 mm diameter). (Ref. drawing on page 22)

On Mounting plate or column

M5 x 20 or 25 with Philips head DIN7985 or Torx. Head diameter 10mm.



On Wall

Panhead – DIN7981 for plug or wooden wall, etc. Head diameter 10.8 B5.5 x 38 or 45 mm





Do not use countersunk screws.



Due to the cabinet material, use as low a tightening torque as possible




⚠ Washers are recommended

- 4. Carry out Electrical connections (chapter 4.3)
- 5. Move the front part back to its original position and fasten the 12 screws.



Do not use more than 2.5Nm torque when fastening the 12 screws in the front frame.


Opening the enclosure 4.2.1



- **1** Open the enclosure by loosening the 2 screws that secure the front frame to the onwall box
- **2** Open the enclosure by pulling the front frame out 5 mm, keeping it parallel to the on-wall box. This is necessary to get clearing for the hinges
- 3 Then pull the right side of the front frame to fully open the enclosure. Make sure to not open the enclosure so far that cables between the front and back parts are pulled tight.

Page 20 Doc. no. A100K11499


4.2.2 Prepare and mount the station



Prepare for drilling 4 Mounting holes in the On Wall Box are Ø6,4mm Distance 298 x 130 Holes to be drilled are depending mounting on wall or mounting column


Location

Please make certain you have clearance of minimum 230mm to left for frame movement



Mounting plate or column

Fix the station to mounting plate or column with four screws that fit the four screw holes in each corner of the on-wall box (6.4 mm diameter). Use M5 x 20 or 25 with Philips head DIN7985 or Torx. Head diameter 10mm.




Wall


Fix the station to the wall with four screws that fit the four screw holes in each corner of the on-wall box (6.4 mm diameter).
Use Panhead –
DIN7981 for plug or wooden wall, etc. Head diameter 10.8 B5.5 x 38 or 45 mm

Page 22 Doc. no. A100K11499

4.3 Electrical connection

All electrical connections are made on the main board inside the housing. See chapter 4.2 for instructions on opening and closing the housing






4.3.1 Connection of audio accessories


The blue connector is marked +, -, S, and numbers 1 to 9 (ref. Figure 2). These should be utilized as follows:

| | + | Integrated Mic + |
|-----|---|------------------------------------|
| J13 | - | Integrated Mic – |
| | S | Chassis ground |
| | 1 | Audio accessory speaker - |
| | 2 | Audio accessory speaker - |
| J6 | 3 | Audio accessory microphone mic + |
| | 4 | Audio accessory microphone mic – |
| | 5 | Audio accessory Push To Talk (PTT) |
| J7 | 6 | Audio accessory Hook |
| | 7 | Audio accessory Ground PTT/Hook |
| | 8 | Loudspeaker + |
| J9 | 9 | Loudspeaker - |




Connection of handheld microphone EMMAX-1H


Page 24 Doc. no. A100K11499



Connection of headset AK5850HS and cable with PTT TAX-2B



Connection of handset TAX-3



Connection of External loudspeaker on TFIX-4

Page 26 Doc. no. A100K11499

4.3.2 Flowire connection

Each Ex Product features two Flowire connectors. Power and signal redundancy can be achieved by utilizing both Flowire connectors in an A-B system configuration.


See general guidelines for cabling in Flowire Installation and Configuration Manual, Doc. no. A100K11422.




Do not connect more than 9 Ex Products to each central Flowire Converter.

Only use one of the Flowire connectors on each Ex product for each central Flowire Converter.

Load sharing power supply must be used for redundant cabling solutions. Consult with Zenitel before implementing this type of solution.




The main board receives both power and Ethernet signals through two wires. You can connect either A or B for connection to the rest of the system, or both A and B, each to a separate server, in order to achieve redundancy.



Connection of Flowire in a single system

Page 28 Doc. no. A100K11499




Connection Flowire in a redundant A-B system

4.3.3 Central connection


The central rack must contain

- A server
- A Flowire Converter (FCDC2)
- A 24V Power Supply Unit (PSU)

In order to connect several Ex Products to one central FCDC2, you also need a terminal block.



Page 30 Doc. no. A100K11499



Industrial Ex products connected to a central server

Industrial Ex products connected to two central servers in a redundant A-B system

Only use 24VDC power supplies sold or recommended by Zenitel for Ex products.

4.3.4 Grounding

To establish explosion-proof protection, it is vital that the grounding of the panel is done according to the following instructions.

All ground and shield cables from the central rack must be terminated on the ground sheet inside the main housing.

Grounding must be done according to IEC 60079-17.

The apparatus does not withstand the electrical strength test with 2 x Um 250V r.m.s. to earth according to clause 6.3.13 of IEC/EN 60079-11: 2011/2012, because the equipment has a connection to earth.

4.3.5 Cable insertion



Only cables certified for use in explosive atmospheres shall be used.



Only Ex certified cable entries made from plastic shall be used.

The prescribed cable diameters and other guidelines for cable entries used shall be observed.



The relevant mounting directives for the cable entries used shall be observed.

When using cable entries with a degree of protection that differs from the IP protection of the Ex Product (see Technical Specifications), the limiting IP protection level shall be adhered to.

When using cable entries with an ambient temperature range that differs from the ambient temperature range of the panel or intercom (see Technical Specifications), the limiting temperature range shall be adhered to.

When using cable entries with impact resistance that differs from the impact resistance of the panel or intercom, the limiting impact resistance shall be adhered to.



Cable entries must have ingress protection IP54 or higher

Cable entries must be approved according to IEC 60079-0:2007 or EN 60079-0:2009 or later versions of one of these standards

In order to ensure the required minimum degree of protection, the cable entries must be tightened down securely.



Over-tightening can impair the degree of protection and damage the Ex Product.

Mhen tightening the cap nut of a cable entry, a suitable tool shall be used to prevent the gland from twisting.

When using the Hummel M16 cable gland HSK-K-MZ-Ex included in the box, the following limiting factors apply

- Lowest temperature -20°C
- Impact resistance: 4J (low risk of mechanical danger)

Commissioning 4.4

Before operating the Ex panels ensure that;

- The national regulations concerning such apparatus are followed.
- An inspection according to the IEC 60079-17 standard has been performed.

Page 32 Doc. no. A100K11499

5 **Maintenance Service**

5.1 General

The valid national regulations for the servicing/maintenance of electrical apparatus for use in potentially explosive atmospheres shall be observed.

Prior to opening the enclosure, it is necessary to ensure that the voltage supply has been isolated or to take suitable protective measures.

The necessary intervals between servicing depend upon the specific application and shall be stipulated by the operator according to the respective operating conditions.

During servicing, explosion protection dependent parts shall be tested to ensure their correct state, such as the following.

5.1.1 Water tight enclosure

- Visual inspection to look for cracks or damages on the enclosure.
- Visual inspection of the screw inserts for the 12 screws connecting the front frame to the on-wall box. If any of these have moved out of their original positions, the integrity of the enclosure is jeopardized.
- Inspect all seals, gaskets and cable entries for efficiency and intactness.
- If water has entered the Ex panel, contact your supplier immediately and do not apply voltage to the panel until it has been inspected and/or replaced by a specialist.

5.1.2 Wires

- Inspect termination points for loose wires.
- Inspect wire isolation and jackets for cracks and signs of ageing.



Do not replace any parts not mentioned in chapter 5.3 without approval from Zenitel.

5.2 **Repair / Overhaul / Modifications**

Only original Zenitel parts shall be used for carrying out repairs that concern explosion protection.

In the event of damage to the enclosures, replacement of these components is mandatory. Contact Zenitel for guidance.

Reconstruction or modifications to the apparatus are only possible within the scope of the approvals and shall be certified afterwards.

5.3 Serviceable / replaceable parts

| Item number | Item Name | Item Description |
|-------------|-----------|---|
| 1000150040 | TAX-4 | Cable gland kit (10x), for TFIX and EAPFX |
| 1023594100 | EGA-1 | Button Protection Covers (10x), for TFIE/TFIX/EAPII/EAPFX |
| 1008140250 | TA-25 | M6 screw kit for TFIE/TFIX and EAPII/EAPFX stations |
| 2330040026 | AK5850HS | Ex-Approved Headset with plug ** |
| 1008150025 | TAX-2B | Ex Approved Cable for Headset with PTT Button |
| 1008150030 | TAX-3 | Ex-Approved Handset with PTT, unterminated |
| 1023533511 | EMMAX-1H | Exigo Handheld Industrial Ex Microphone, 1 Button, IP66 |

^{**} Headset AK5850HS is only certified for use in ATEX areas (Not IECEx)

5.4 End of life, the WEEE directive

The WEEE Directive does not legislate that Zenitel, as a 'producer', shall collect 'end of life' WEEE.

This 'end of life' WEEE should be recycled appropriately by the owner who should use proper treatment and recycling measures. It should not be disposed to landfill.

Many electrical items that we throw away can be repaired or recycled. Recycling items helps to save our natural finite resources and also reduces the environmental and health risks associated with sending electrical goods to landfill.



Under the WEEE Regulations, all new electrical goods should now be marked with the crossed-out wheeled bin symbol shown.

Goods are marked with this symbol to show that they were produced after 13th August 2005, and should be disposed of separately from normal household waste so that they can be recycled.

Page 34 Doc. no. A100K11499

6 Appendix

6.1 Main Technical specification

| Physical | | | | |
|----------------------------|---|--|--|--|
| Size (HxWxD): | 345 x 188 x 101 mm | | | |
| Weight: | 4'000 gram | | | |
| Acoustical | | | | |
| Audio output : | > 90 dB * | | | |
| Frequency response | 150 – 20 000 Hz * | | | |
| Environmental | | | | |
| Storage temperature | -40°C to 70°C | | | |
| Operating temperature (T4) | -20°C to 60°C | | | |
| Ingress protection | IP 66 / IP 64 ** | | | |
| Impact resistance | Fit for areas with high risk of mechanical danger *** | | | |
| Safety | | | | |
| IECEx (IEC EN 60079) | II 2(2)G Ex e ib mb [ib] IIC T4 Gb+ | | | |

For detailed information about electrical and operational specifications please see chapter 3 and datasheets.


^{*} TFIX versions only

^{**} IP 66 tested in accordance with EN60945, IP 64 tested in accordance with IEC 60079-0


^{***} When using cable entry "Hummel M16 cable gland HSK-K-MZ-Ex", included with the Ex industrial panels and intercoms, impact resistance is limited to areas with low risk of mechanical danger

6.2 Dimension Drawings

6.2.1 TFIX-1, TFIX-2, TFIX-3, TFIX-3, TFIX-4, EAPFX-1, EAPFX-6




6.2.2 AK5058HS & TAX-2B




Page 36 Doc. no. A100K11499

6.2.3 TAX-3



6.2.4 EMMAX-1H



www.zenitel.com

Zenitel Norway AS P.O. Box 4498 Nydalen NO-0403 OSLO Norway

DOC NO.



