

VINGTOR STENTOFON

ENA2100-AC Amplifier Mounting Manual

1 Mounting the ENA2100-AC Amplifier

This document describes the procedure for mounting the ENA2100-AC amplifier in a 19-inch rack.


Zenitel takes no responsibility for damages caused by improper or inadequate mounting.

The ENA2100-AC can be installed either in a single or double mounting configuration using the mounting kits ENA2100-Single and ENA2100-Double respectively.

Item Number	Item Name	Item Description
1023102100	ENA2100-AC	Exigo Network Amplifier 2 x 100W
1023532100	ENA2100-Single	Mounting Kit for Single ENA2100-AC (Blanking Plate & Angle Joint)
1023532110	ENA2100-Double	Mounting Kit for Double ENA2100-AC (Angle Joint)

2 Mounting Single Amplifier

To mount a single amplifier, use the ENA2100-Single mounting kit consisting of a Blanking Plate and an Angle Joint.



- Align the holes on the flanges of the amplifier and the blanking plate with the holes on the angle joint.



- Fasten them together with four standard rack screws.



3 Mounting Double Amplifiers

To mount double amplifiers, the Angle Joint is used.

- Align the holes on the flanges of both amplifiers with the holes on the angle joint.



- Fasten them together with four standard rack screws.

