

## CHARGERS AND BATTERY PACKS

- Chargers operate in a 50° to 85° F (10° to 30°C) environment. Do not expose them to freezing temperatures or direct sunlight.
- Do not place anything in the charging bay other than a single Battery Pack as appropriate to avoid bending the contacts. Bent contacts can keep the Battery Pack from charging.
- Only use genuine Spectralink 84-Series Battery Packs with Spectralink 84-Series Chargers.
- Never use a non-genuine charging unit as it could damage the Battery Pack.
- Use only the original plug-in power adapter for the chargers.
- Contact your service representative for assistance if you have a faulty Battery Pack or a problem with your charger.
- Any battery that exhibits swelling, cracking or other abnormality should be disposed of promptly and properly.



### WARNING: DO NOT...

DO NOT IMMERSE THE BATTERY PACK IN WATER OR THROW IT INTO FIRE.



### WARNING: DO NOT...

DO NOT DISPOSE OF THE BATTERY PACK WITH YOUR DOMESTIC WASTE. TAKE USED BATTERY PACKS TO AN APPROPRIATE COLLECTION POINT FOR RECYCLING OR SEND THEM BACK TO YOUR SUPPLIER OR SERVICING AGENT.



### WARNING: DO NOT...

ALL BATTERIES CAN CAUSE PROPERTY DAMAGE AND/OR BODILY INJURY, SUCH AS BURNS, IF A CONDUCTIVE MATERIAL SUCH AS JEWELRY, KEYS, OR BEADED CHAINS TOUCHES EXPOSED TERMINALS. THE CONDUCTIVE MATERIAL MAY COMPLETE AN ELECTRICAL CIRCUIT (SHORT CIRCUIT) AND BECOME QUITE HOT. EXERCISE CARE IN HANDLING ANY CHARGED BATTERY, PARTICULARLY WHEN PLACING IT INSIDE A POCKET, PURSE, OR OTHER CONTAINER WITH METAL OBJECTS.



### WARNING: DO NOT...

**WARNING:** THE BATTERY USED IN THIS DEVICE MAY PRESENT A RISK OF FIRE OR CHEMICAL BURN IF MISTREATED. DO NOT DISASSEMBLE, HEAT ABOVE 45°C, OR INCINERATE. REPLACE BATTERY WITH SPECTRALINK MODEL RS657 OR RS658 ONLY. USE OF ANOTHER BATTERY MAY PRESENT A RISK OF FIRE OR EXPLOSION.

## Contact Information

### Spectralink Corporation

**US Location**  
800-775-5330  
2560 55th Street  
Boulder, CO 80301  
[info@spectralink.com](mailto:info@spectralink.com)

**European Location**  
+45 7560 2850  
Spectralink Europe ApS  
Langmarksvej 34  
8700 Horsens, Denmark  
[infodk@spectralink.com](mailto:infodk@spectralink.com)

## Potentially Explosive Atmospheres

Do not take your handset, charger, or battery into any area with a potentially explosive atmosphere. Do not remove, install, or charge batteries in such areas. Sparks in a potentially explosive atmosphere can cause an explosion or fire resulting in bodily injury or even death.



### NOTE: TYPES OF EXPLOSIVE ATMOSPHERES

AREAS WITH POTENTIALLY EXPLOSIVE ATMOSPHERES INCLUDE FUELING AREAS SUCH AS BELOW DECKS ON BOATS, FUEL OR CHEMICAL TRANSFER OR STORAGE FACILITIES, AREAS WHERE THE AIR CONTAINS CHEMICALS OR PARTICLES SUCH AS GRAIN, DUST, OR METAL POWDERS, AND ANY OTHER AREA WHERE YOU WOULD NORMALLY BE ADVISED TO TURN OFF YOUR VEHICLE ENGINE. AREAS WITH POTENTIALLY EXPLOSIVE ATMOSPHERES ARE OFTEN POSTED, BUT NOT ALWAYS.

## ELECTROMAGNETIC INTERFERENCE AND COMPATIBILITY



### NOTE: ELECTROMAGNETIC INTERFERENCE

NEARLY EVERY ELECTRONIC DEVICE IS SUSCEPTIBLE TO ELECTROMAGNETIC INTERFERENCE (EMI) IF INADEQUATELY SHIELDED, DESIGNED, OR OTHERWISE CONFIGURED FOR ELECTROMAGNETIC COMPATIBILITY.

## Facilities

To avoid electromagnetic interference and/or compatibility conflicts, do not install charging stations in any area where posted notices instruct you to turn off handsets/cell phones. Hospitals or health care facilities may be using equipment in certain areas that is sensitive to external RF energy.

## Copyright Notice

© 2013-2014 Spectralink® Corporation All rights reserved. Spectralink, the Spectralink logo and the names and marks associated with Spectralink's products are trademarks and/or service marks of Spectralink Corporation and are common law marks in the United States and various other countries. All other trademarks are property of their respective owners. No portion hereof may be reproduced or transmitted in any form or by any means, for any purpose other than the recipient's personal use, without the express written permission of Spectralink.

All rights reserved under the International and pan-American Copyright Conventions. No part of this manual, or the software described herein, may be reproduced or transmitted in any form or by any means, or translated into another language or format, in whole or in part, without the express written permission of Spectralink Corporation.

Do not remove (or allow any third party to remove) any product identification, copyright or other notices.

## Notice

Spectralink Corporation has prepared this document for use by Spectralink personnel and customers. The drawings and specifications contained herein are the property of Spectralink and shall be neither reproduced in whole or in part without the prior written approval of Spectralink, nor be implied to grant any license to make, use, or sell equipment manufactured in accordance herewith. Spectralink reserves the right to make changes in specifications and other information contained in this document without prior notice, and the reader should in all cases consult Spectralink to determine whether any such changes have been made.

NO REPRESENTATION OR OTHER AFFIRMATION OF FACT CONTAINED IN THIS DOCUMENT INCLUDING BUT NOT LIMITED TO STATEMENTS REGARDING CAPACITY, RESPONSE-TIME PERFORMANCE, SUITABILITY FOR USE, OR PERFORMANCE OF PRODUCTS DESCRIBED HEREIN SHALL BE DEEMED TO BE A WARRANTY BY SPECTRALINK FOR ANY PURPOSE, OR GIVE RISE TO ANY LIABILITY OF SPECTRALINK WHATSOEVER.

# Spectralink 84-Series 12-Bay Multi-Charger

The 12-Bay Multi-Charger is an assembly of three Quad Chargers on a rack that is wall or desk mountable and uses one power cord. It is designed for bulk charging in fast-moving mobile environments where desktop chargers are not an efficient option.

## INSTALLATION AND OPERATION

### Package contents

- 12-Bay Multi-Charger assembly with power cord strain relief installed
- Power supply
- AC Power Cord for your region
- This document

### You will need to supply

- Four (4) ¼" pan head screws suitable for the mounting surface.

### Installation Instructions

- Use the template on the back of this document to define the 12-Bay Multi-Charger mounting area and mark the four screw holes. Drill four pilot holes for the screws, if needed.
- Slide the top and bottom Quad Chargers out of their brackets to expose the screw holes:  
The chargers are attached to the rack with four hooks. Use both hands to slide the charger up (in a direction away from the power connector) to unhook it from the rack. Unplug the cable and set the charger aside.  
Do this for the top and bottom chargers.
- Install four ¼" pan head screws appropriate for the particular wall (wood screws into studs, sheet rock lugs and screws, metal screws for metal studs, etc.). Leave the screw heads about 3/8" out from the wall.
- Hang the 12-Bay Multi-Charger rack on the four screws and once in place, tighten the screws.
- Reconnect the Quad Chargers:  
Plug the cable back into the charger and use both hands to position the charger flat against the rack above its final position. Slide the charger over the hooks ensuring that all four hooks are set. Do this for both chargers.
- Plug the main power supply into the connector at the bottom of the rack. One cable clamp and its mounting screw are assembled on the unit. Use it to secure the power supply cable. Adjust it to whichever side of the connector is best for your installation. Plug the correct power cord for your area into the power supply.
- Plug the power cord into the power source. The unit is now operational. There is no on/off switch.



### CAUTION: INSTALLATION RESTRICTIONS

DO NOT MOUNT THE 12-BAY MULTI-CHARGER WHERE IT WILL EXPOSE CHARGES OR HANDSETS TO POTENTIALLY EXPLOSIVE ATMOSPHERES OR EXPOSE PERSONNEL OR EQUIPMENT TO INAPPROPRIATE ELECTROMAGNETIC INTERFERENCE.

### Charging Instructions

The Battery Packs snap into the individual charging slots. The LED just above the charging slot indicates the charging status of the Battery Pack. The following table lists the LED indications and Battery Pack status.

LED Indication	Battery Pack Status
Blinking	Charging
Solid green	Fully charged
Off	Not properly seated or empty

### Battery Packs

Two types of Battery Packs are available: Standard and Extended. The battery label identifies its type.

Type	Talk Time	Standby Time	Charging Time
Standard (RS657)	8 hours	80 hours	3.5 hours (typical)
Extended (RS658)	12 hours	120 hours	5 hours (typical)



### WARNING: EXPLOSION RISK

**WARNING:** THERE IS A RISK OF EXPLOSION IF YOU REPLACE THE BATTERY PACK WITH AN INCORRECT TYPE. ONLY USE SPECTRALINK MODEL RS657 OR RS658 BATTERY PACKS WITH SPECTRALINK 84-SERIES WIRELESS HANDSETS. DISPOSE OF USED BATTERIES ACCORDING TO THE INSTRUCTIONS.



### CAUTION: PRODUCT COMPATIBILITY / SAFETY

**CAUTION:** SPECTRALINK 84-SERIES HANDSETS ARE INTENDED FOR OPERATION ONLY WITH SPECTRALINK 84-SERIES BATTERY PACKS AND SPECTRALINK 84-SERIES CHARGERS. THESE SPECTRALINK COMPONENTS ARE CRITICAL TO PRODUCT SAFETY CERTIFICATION AND MAY NOT BE SUBSTITUTED. REPRESENTATIVE SAMPLES OF THE SPECTRALINK 84-SERIES HANDSETS, BATTERY PACKS AND CHARGERS HAVE BEEN TESTED AS A COMPLETE SYSTEM BY AN INDEPENDENT TESTING ORGANIZATION AND HAVE BEEN CERTIFIED BY THAT ORGANIZATION TO MEET APPLICABLE SAFETY STANDARDS. USE OR OPERATION OF THE SPECTRALINK 84-SERIES HANDSETS WITH BATTERIES OR CHARGERS OTHER THAN THOSE AUTHORIZED BY SPECTRALINK HAS NOT BEEN TESTED OR SAFETY CERTIFIED. SPECTRALINK 84-SERIES HANDSETS, BATTERY PACKS OR CHARGERS USED OR OPERATED WITH PRODUCTS NOT AUTHORIZED BY SPECTRALINK ARE NOT COVERED BY THE SPECTRALINK LIMITED PRODUCT WARRANTY.



### CAUTION: USE AUTHORIZED COMPONENTS ONLY

**CAUTION:** ONLY SPECTRALINK 84-SERIES BATTERY PACKS AND SPECTRALINK 84-SERIES CHARGERS ARE AUTHORIZED FOR USE OR OPERATION WITH SPECTRALINK 84-SERIES HANDSETS. ONLY SPECTRALINK 84-SERIES BATTERY PACKS ARE AUTHORIZED FOR USE OR OPERATION WITH A SPECTRALINK 84-SERIES CHARGER.

WALL MOUNTING TEMPLATE

